


# OIL MATE

## 16-LITRE OIL PAN & HOLDER FOR TRANSMISSION JACK

THIS TOOL IS AN INDISPENSABLE ASSISTANCE WITH AUTOMOTIVE OIL WORK,  
ENSURING QUICK, CLEAN CHANGES AND EASY DRAINAGE

### HOW TO USE

- » FIT OIL MATE TO ANY STANDARD TRANSMISSION JACK USING THE MOUNTING POINT ON THE BASE.
- » POSITION THE PAN CENTERED BELOW THE FLOW OF OIL.
- » WHEN YOUR WORK IS COMPLETED MOVE THE DRAINAGE SPOUT DIRECTLY OVER THE DISPOSAL POINT AND LIFT THE REAR HANDLE SLOWLY TO POUR OUT OIL.



MUST HAVE  
ITEM.



### KEY BENEFITS

- » OIL MATE'S MOUNTING POINT FITS STANDARD EUROPEAN TRANSMISSION JACKS.
- » TILTING OIL PAN IS REMOVABLE AND REPLACABLE (71002-WW & 71001-WW)
- » ANTI-SPILL INNER RIM AND TRIPLE CHANNEL SPOUT FLOW SYSTEM HELP MINIMISE SPILLS.



### INNOVATIVE DESIGN

- » THE COMBINATION OF AN EYE CATCHING DESIGN WITH INNOVATIVE FEATURES, A UNIVERSAL MOUNTING SYSTEM AND REPLACABLE PANS MAKE THIS AN ESSENTIAL PIECE OF KIT FOR ANY MECHANIC.



WELZH®

[www.welzh.com](http://www.welzh.com)